

Register your Gatekeeper Mini



This guide is only for the Gatekeeper Mini. For other Gatekeeper models, please refer to the following link:
<https://www.gymmaster.com/hardware-documents/>

The Gatekeeper software comes in a test mode. To register and use your Gatekeeper, please follow the instructions below:

If you encounter any issues during the process, please refer to our troubleshooting guide at:
<https://www.gymmaster.com/troubleshooting/>

Step 1: Power up the Gatekeeper

1. Connect the **Ethernet cable**.
2. Plug in the **power** cable on the Gatekeeper and wait 20 seconds.
3. Confirm that the **Ethernet port LEDs** are lit with a solid orange light and a flashing green light.
4. Connect any readers.

Step 2: Register the Gatekeeper

Note: You need Admin access under *Administrative* to be able to register the Gatekeeper. You can configure this in GymMaster under **Settings > User Administration > Permissions**.

1. Go to: www.gymmaster.com/registergk.
2. Enter your **GymMaster login** details.
3. Click **Continue**.
4. Enter the Gatekeeper details:
 - a. **Club** – Select the GymMaster club this Gatekeeper will be linked to.
 - b. **Gatekeeper Version** - As found on the sticker on the Gatekeeper, select **Gatekeeper Mini**.
 - c. **Location** - Specify the physical location of the Gatekeeper (choose a unique name for easier identification later).
 - d. **Gatekeeper Code** - Enter the MAC address in this format: '00:00:00:00:00:00', found on the Gatekeeper sticker. **Note:** No need to worry about capitalization.
5. Click **Submit**.
6. Go to **Settings > Doors & Readers > New Door**. If the Gatekeeper name appears under the **Hardware Configuration**, then your Gatekeeper has been successfully set up.

The screenshot shows a web form titled "Register Gatekeeper". It includes a "Quick Instructions" section with four steps: 1. Power up the gatekeeper and connect all door readers. 2. Enter your GymMaster admin login. 3. Enter the gatekeeper code and details. 4. Reboot the gatekeeper. The form fields are: Email (help@treshna.com), Password (masked with dots), Club (test), Gatekeeper Version (Gatekeeper Mini), Location (Main door), and Gatekeeper Code (E2:5F:33:86:C1:T6). There is an "Enable Tailgate" checkbox which is unchecked, and a blue "Submit" button. At the bottom, it says "Powered by GYMMASTER".

If you require any help or encounter any issues, please contact GymMaster support.